



## PS3 Ultimate Controller

ITEM #29033-G

- Sixaxis sensor function.
- 8 way D-pad, 4 fire buttons and 4 shoulder fire buttons.
- Start button, Select button and PS button.
- Two analog control sticks.
- 4 LED indicators for the controller channel in use (LED1 + LED4: 5th channel, LED2 + LED4: 6th channel, LED3 + LED4: 7th channel).
- Working current: 30mA.
- Cable length: 1.8m.