



25010 PS4 screen clip

1. Enable the PS4 Camera fixing on the screen
2. Apply to the screen depth less than 5cm
3. Available in various colors